

Chart No.6. Structure Components of the Land Leveler


Chapter 2 System Installation

1. Installation of Mechanical Parts

The Whole Scraper includes: Scraper, Wheel Carrier (Axle), Triangle Draw Bar, Lead Screw, Mast.

With the Hinge Pin to link the Three parts (Scraper, Wheel Carrier and Triangle Draw Bar) in order. The Triangle Draw Bar can be lifted up after install the Lead Screw. Because the Mast have screw thread, so it can be rotated to the Scraper.

Top View of Whole Scraper :



Side Elevation of the Whole Scraper :




Image of The Whole Scraper :



Image of Scraper Parts :



Image of Rear-Wheel :



Image of Triangle Draw Bar :



Image of Lead Screw :

